Connecting External Antennas

120300094000J-Paddle Antenna

Power off the Gateway. Ensure the Gateway is powered off and unplugged from the power outlet.

Align antennas and tighten. Connect the six antennas to their appropriate ports on the Gateway. Ensure the labels on the ports match those on the antenna labeled either Wi-Fi or 4G/5G. Please ensure the antennas are securely hand tightened for optimal performance.

Position antennas.

For the best reception, position the antennas so that they are in an upright position as illustrated. Once completed, please plug in and power on the device.

